Driveshaft and Axle

GENERAL		DS -2
	ASSEMBLY	DS -10
DRIVESHAFT		DS -20
FRONT AXLE		DS -30
REAR AXLE	The weath	DS -46
	RIER ASSEMBLY	

GENERAL

GENERAL EIUC0010

PROPELLER SHAFT

TOTAL LENGTH (FRONT/REAR)

Classification		Specification (mm/in.)			
Classification		T2 (T26)	TC (D4BF)	4D56TCI (D4BH)	SIRIUS II (2.4L)
Short wheel base (No.6)	M/T	1709 (927/782) 67.3 (36.5/30.8)	1709 (927/782) 63.3 (36.5/30.8)	1653 (888/765) 65.1 (35/30.2)	1726 (944/782) 68 (37.2/30.8)
·	A/T	1536 (754/782) 60.5 (29.7/30.8)	1536 (754/782) 60.5 (29.7/30.8)	1536 (754/782) 60.5 (29.7/30.8)	1585 (803/782) 62.4 (31.6/30.8)
Short wheel base (No.7)	M/T	1692 (927/765) 66.6 (36.5/30.2)		1653 (888/765) 65.1 (35/30.2)	-
	A/T	1519 (754/765) 59.8 (29.7/30.2)	-	1519 (754/765) 59.8 (29.7/30.2)	-
Long wheel base (No.6)	M/T	1980 (927/1053) 78 (36.5/41.5)	1980 (927/1053) 78 (36.5/41.5)	1919 (888/1031) 75.6 (35/40.6)	1997 (944/1053) 78.6 (39.1/41.5)
<u>.</u> L	A/T	1807 (754/1053) 71.1 (29.7/41.51)	1807 (754/1053) 71.1 (29.7/41.51)	1807 (754/1053) 71.1 (29.7/41.51)	1859 (803/1053) 73.2 (31.6/41.5)
Long wheel base (No.7)	M/T	1958 (927/1031) 77.1 (365/40.3)	-	1919 (888/1031) 75.6 (35/40.6)	1975 (944/1031) 79.8 (39.1/40.6)
	A/T	1785 (754/1031) 70.3 (29.7/40.6)	. -	1785 (754/1031) 70.3 (29.7/40.6)	1834 (803/1031) 72.2 (31.6/40.6)
4WD (No.7)	M/T	-	Front: 401 (15.8) 277 (552.5/724.5) 50.3 (21.8/28.5)	Front: 439 (17.3) 1242 (482/706) 48.9 (19/27.8)	
	A/T	-	<u>-</u>	Front: 465 (18.3) 1216 (456/760) 47.9 (18/30)	· •
Run-out		0.5 mm (0.02 in.) or less			·

FRONT AXLE AND DRIVESHAFT

Classification	Specification		
Classification	2WD	4WD	
Front axle hub bearing type	Taper roller bearing	←	
Driveshaft joint type - Outer - Inner	_	A.C G.I	
Front differential - Reduction gear type - Reduction gear ratio		Hypoid 4.625 (No.7) : 4D56TCI 4.875 (No.7) : T/C, 2.4 MPI	

REAR AXLE

	Classification		Specification	
Ax	xle housing type		Banjo type	
Dif	ferential			
-	Reduction gear type		Hypoid gear	
-	Reduction gear ratio		· · · · · · · · · · · · · · · · · · ·	
		2WD	3.909 (No.6) - (Wagon, short wheel base, 4D56T/C) - (Wagon, short wheel base, 4D56TCI, A/T) - (Wagon, long wheel base, 4D56TCI 7/9 persons) 4.222 (No.6) - (Wagon, short wheel base, T-2 or 2.4 MPI) - (Wagon, long wheel base, T-2 or 2.4 MPI) - (Wagon, long wheel base, 4D56TCI, A/T, 12 persons)	ons)
			3.909 (No.7) - (Wagon, short wheel base, 4D56TCI, 9 persons) - (Wagon, long wheel base, 4D56TCI, 9 persons) - (VAN, 4D56TCI, 6 persons)	
		ng é	4.222 (No.7) - (VAN, T-2 or 2.4 MPI) - (VAN, 4D56TCI, A/T, 3 persons)	A CONTRACTOR OF THE STATE OF TH
		4WD	4.625 (No.7) - (Wagon, 4D56TCI)	
			4.875 (No.7) - (Wagon, TC or 2.4 MPI)	

LUBRICATIONS EIUC0020

Items	Specified lubricants	Quantity
Propeller shaft joint	ALVANIA EP Grade No.2	As required
Front driveshaft - A.C joint - G.I joint	Century One Luber GKN	185 ± 10 gr. 200 ± 10 gr.
per ett för seke för Livet komme	 (Hipoid gear oil) General and frigid zone: API GL-5 class (SAE 80W/90) Severs heat zone: API GL-4 class (SAE 140) 	Fill the reservoir to the plug hole.
	 General zone (-30°C - +30°C): API GL-4 class (SAE 90) Severs heat zone (+30°C MIN.): API GL-4 class (SAE 140) Severe frigid zone (-30°C MAX.): API GL-5 class (SAE 80) 	Fill the reservoir to the plug hole.
- With LSD	API GL-4 class (SAE 90), Mobile Korea infilrex 33 or equivalent	

TORQUE SPECIFICATIONS EIUC0030

Items 594350	Nm ·	Kg⋅cm	lb·ft
Propeller shaft			
Yoke flange mounting nut (Front, Rear)	50 - 60	500 - 600	37 - 44
VL assembly to transfer flange mounting nut	30 - 40	300 - 400	23 - 29
Center bearing mounting self locking flange nut	40 - 50	400 -500	29 -37
Center bearing mounting bracket	70 - 95	700 - 950	
Self locking nut to center yoke mounting lock nut (2WD)	230 - 250	2300 - 2500	168 - 183
Wheel nut - 2WD - 4WD	150 - 200 120 - 140	1500 - 2000 1200 - 1400	111 - 148 88 - 103.6
Front/Rear steel band	19 - 28	190 - 280	14 - 21
Front hub to brake disc mounting	50 - 60	500 - 600	37 - 44
Upper arm ball joint to knuckle mounting	120 - 180	1200 - 1800	88 - 132
Lower arm ball joint to knuckle mounting	120 - 180	1200 - 1800	88 - 132
Knuckle to tie rod end mounting	35 - 45	350 - 450	26 - 33
Front shock absorber lower mounting	90 -105	900 - 1050	67 - 78
Driveshaft to inner shaft mounting	80 - 100	800 - 1000	59 - 74
Rear axle housing to bearing case	50 - 60	500 - 600	37 - 44
Oil filler plug	40 - 60	400 - 600	29 - 44
Oil drain plug	50 - 70	500 - 700	37 - 51
Differential self-locking nut	190 - 250	1900 - 2500	141 - 185
Free wheel hub mounting bolt	50 - 60	500 - 600	37 - 44



CAUTION

Replace self-locking nuts with new ones after removal.

SEALANTS AND ADHESIVES EIUC0040

Items	Specified sealants and adhesives
Contact surface of the free wheel hub and hub	LOCKTITE #587 or equivalent
Differential cover installation surface (to gear carrier)	THREEBOND #1215 or equivalent
Contact surface of the rear axle housing and bearing case	LOCKTITE #587 or equivalent

SPECIAL TOOL EIUC0050

Tool (Number and Name)	Illustration	Use
09493-43000 Universal joint remover and installer		Removal and installation of the journal bearing (Use with 09432-43100)
	D9343000	
09493-43100 Universal joint remover adapter	Collar	Removal and installation of the journal bearing (Use with 09452-43000)
	D9343100	
09517-43001 Bearing and gear puller		Removal of the center bearing Removal of the differential side bearing
	E1743001	
09526-11100 Sliding hammer		Removal of the oil seal
	AU52-04A	

Tool (Number and Name)	Illustration	Use
09517-21400 Draft		 Removal of the rear hub bearing outer race Removal of the front hub outer bearing outer race and inner bearing outer race
	E1721400	
09500-21000 Bar	D)	 Installation of the axle shaft bearing outer race Installation of the drive pinion bearing outer race Installation of the oil seal
	E0021000	
09432-33400 Bearing race installer		
	AU52-04F	
09527-4A000 Removing plate		Removal of the drive pinion rear bearing inner race
	E274A000	
09568-34000 Ball joint puller		Disconnection of the tie rod
	E6834000	
09532-31200 Oil seal installer		 Installation of the drive pinion outer race (Use with 09500-11000) Installation of the front hub outer bearing outer race (Use with 09500-11000)
	E3212000	

Tool (Number and Name)	Illustration	Use
09532-32000 Bearing installer		Installation of the drive pinion front bearing outer race
	E3232000	
09517-43400 Working base		Support for the differential carrier
	E1743400	
09517-43500 Adapter		
	AU52-05B	
09521-43001		Adjustment of the side bearing nut
Side bearing adjust spanner		
	AU52-051	
09500-43131 (NO. 6) 09500-4A000 (NO. 7) Pinion height gauge		Measurement of the drive pinion height
	AU52-05D	
09500-4A100 (NO. 7) Pinion height gauge base		
to the state of th	E004A100	

Tool (Number and Name)	Illustration	Use
09532-11600 Preload socket	E3211600	Measurement of the drive pinion starting torque (Use with torque wrench)
09517-21700 Eng yoke holder		Removal and installation of the companion flange
	E1721700	

TROUBLESHOOTING EIUC0060


Symptom		Probable cause	Remedy
Propeller shaft	Noise at start	Worn journal bearing	Replace
		Worn sleeve yoke spline or flange yoke	Replace
	en e	Loose propeller shaft installation	Retighten
	Noise and vibration	Unbalanced propeller shaft	Replace
	at high speed	Improper snap ring selection	Adjust the clearance
		Worn journal bearing	Replace
Axle shaft,	Noise while wheels	Bent axle shaft	Replace
axle housing	are rotating	Worn or scarred axle shaft bearing	Replace
	Grease leakage	Worn or damaged oil seal	Replace
		Malfunction of bearing seal	Replace
Driveshaft,	Noise while wheel	Housing tube bent	Replace
inner shaft	rotation	Inner shaft bent	Replace
		Inner shaft bearing worn, pounding	Replace
		Driveshaft assembly worn damaged, bent	Check or replace
	Noise due to	Inner shaft and side gear serration play	Replace
:	excessive play of wheel in turning	Driveshaft and side gear serration play	Replace
	direction	Driveshaft and drive flange serration play	Replace
	Noise due to	Driveshaft and drive flange end play	Adjust or replace
	excessive wheel end play	Drive flange looseness	Tighten or replace

Symptom		Probable cause	Remedy
Differential	Constant noise	Improper drive gear and drive pinion gear tooth contact	Correct or replace
		Loose, worn or damaged side bearing	
		Loose, worn or damaged drive pinion bearing	
		Worn drive gear, drive pinion	No.
		Worn side gear thrust washer or pinion shaft	
		Deformed drive gear of differential case	
		Damaged gear	
		Foreign material	Eliminate the foreign (Replace the parts if necessary)
		Insufficient oil	Replenish
	Gear noise while	Poor gear engagement	Correct or replace
	driving	Improper gear adjustment	
		Improper drive pinion preload adjustment	
		Damaged gear	Replace
		Foreign material	Eliminate the foreign material and check (Replace the parts if necessary)
		Insufficient oil	Replenish
	Gear noise while coasting	Improper drive pinion preload adjustment	Correct or replace
		Damaged gear	Replace
	Bearing noise while driving or coasting	Cracked or damaged drive pinion rear bearing	Replace
	Noise while turning	Loose side bearing	Replace
		Damaged side gear, pinion gear or pinion shaft	
	Heat	Improper gear backlash	Adjust
		Excessive preload	t je ko nago
		Insufficient oil	Replenish
	Oil leakage	Differential carrier not tightened	Retighten, apply sealant,
		Seal malfunction	or replace the gasket
		Worn or damaged oil seal	Replace
		Excessive oil	Adjust the oil level

PROPELLER SHAFT **ASSEMBLY**

PROPELLER SHAFT

COMPONENTS EIUC0070




REMOVAL EIUC0080

 Remove the tightening bolts of the differential companion flange and flange yoke and remove the propeller shaft.


NOTE

When removing the propeller shaft, be careful not to damage the boot. Insert a piece of cloth into the boot to prevent it from being damaged.



H7PS0280


2. Use the plug as a cover so that no foreign material gets into the transmission or transfer case.



AU49-05A

INSPECTION EIUCOO90


- Check the sleeve yoke, center yoke and flange yoke for wear, damage or cracks.
- Check the propeller shaft yokes for wear, damage or cracks
- Check the propeller shaft for bends, twisting or damage.
- Check the universal joints for smooth operation in all directions.
- 5. Check the center bearing for smooth movement.
- Check the center bearing mounting rubber for damage or deterioration.



EIUC009A

Measure the propeller shaft runout with a dial indicator.

Limit: 0.5 mm (0.02 in.)



AU49-05C


INSTALLATION SERVICE POINTS

EIUC0100

Apply the specified hypoid gear oil to the sleeve yoke.

Specified gear oil:

Hypoid gear oil API classification GL-4 or higher/SAE viscosity 80W, 75W/85W




EIUC010A

2. Install the propeller shaft to the companion flange, aligning with matchmark as closely as possible.


CAUTION

- Be careful not to damage the lip section of the oil seal when installing the propeller shaft.
- If there is grease on the thread parts, wash it off not to loosen them.



AU49-04B

DISASSEMBLY AND REASSEMBLY EIUCO110




EIUB011A

DISASSEMBLY SERVICE POINTS EIUC0120

SNAP RING

- Make matchmark on the yokes of the universal joint that is to be disassembled.
- Remove the snap rings from the yoke with snap ring pliers.




EIMB110A

JOURNAL BEARING

Force out the journal bearings from the propeller shaft yoke with a special tool by the following procedures.

- 1. Install collar to the special tool properly.
- 2. Press a journal bearing by using the special tool to force out the journal bearing on opposite side.



AU49-06C

3. Remove the journal bearing from the yoke.

AUTION

Do not tap the journal bearings to remove them, as this will up set the balance of the propeller shaft.



AU49-06D

4. Press the journal shaft using the special tool to remove the remaining bearing, and remove the yoke.


County Shows States for the State States

CENTER YOKE

Make matchmark on the propeller shaft and center yoke. Then, remove the lock nut from the center yoke and remove the center yoke.




Do not reuse the lock nut.



H7PS0130

CENTER BEARING

After removing the rubber mount, remove the center bearing by using the special tool.



EIMB110C

REASSEMBLY

EIUC0130

JOURNAL AND JOURNAL BEARING


- Apply specified grease to the following parts of universal joint kit .:
 - 1) Shafts and grease sumps of journal.
 - 2) Dust seal lips.
 - Needle roller of bearings.

Specified grease: ALVANIA EP GRADE NO.2



/!\ CAUTION

Use of excessive amounts of grease may result in difficulty in assembling unit and incorrect selection of snap rings.



H7RA1110

- Use the special tool to press the journal bearing into the yoke until the snap ring groove is fully visible.
- Use the special tool to press the opposite side journal bearing into the voke.




/!\ CAUTION

Be careful when pressing the journal bearings, as if they are pressed at an angle, the inside of the journal bearing will be damaged by the journal.



H7PS0200


Align the matchmark on the yoke and propeller shaft, and install the propeller shaft journal bearings in the method described in 2 and 3 above.



H7PS0210

ADJUSTMENT OF JOURNAL END PLAY


- Install the snap rings of the same thickness onto both sides of each yoke with the snap ring pliers.
- Press the bearing and journal into one side with the brass bar.



AU49-07D

Measure the clearance shown in the illustration with a feeler gauge. If the clearance exceeds the standard value, adjust by changing the thickness of the snap


Standard value: 0 - 0.03 mm (0 - 0.0012 in.) or less



H7PS0330


CENTER BEARING ASSEMBLY/CENTER YOKE

1. Install the center bearing assembly to the front propeller shaft as shown in the illustration.




H7PS0260

- 2. Align the matchmark on the center yoke and front propeller shaft.
- 3. Press fit the center bearing with the center yoke while tightening the self-locking nut.



H7PS0170

COMPONENTS EIUC0140



- 1. Snap ring
- 2. Grease fitting
- 3. Journal bearing
- 4. Journal

- 5. Flange yoke
- 6. Sleeve flange
- 7. Front propeller shaft assembly


TORQUE: Nm (kg·cm, lb·ft)

EIUB012A

DISASSEMBLY SERVICE POINTS EIUC0150

SNAP RING

- 1. Make matchmark on the yokes of the universal joint that is to be disassembled.
- 2. Remove the snap rings from the yoke with snap ring pliers.




EIMB110A

JOURNAL BEARING

Force out the journal bearings from the propeller shaft yoke with a special tool by the following procedures.

- Install collar to the special tool properly.
- Press a journal bearing by using the special tool to force out the journal bearing on opposite side.




AU49-06C

Remove the journal bearing from the yoke.



Do not tap the journal bearings to remove them, as this will up set the balance of the propeller shaft.




AU49-06D

Press the journal shaft using the special tool to remove the remaining bearing, and remove the yoke.

SLEEVE FLANGE REMOVAL

Place a matchmark on the sleeve flange and front propeller shaft assembly, remove the sleeve flange.



H7PS0310

REASSEMBLY EIUC0160

JOURNAL AND JOURNAL BEARING

- 1. Apply specified grease to the following parts of universal joint kit.:
 - Shafts and grease sumps of journal.
 - Dust seal lips.
 - Needle roller of bearings.


Specified grease:

ALVANIA EP GRADE NO.2



/ CAUTION

Use of excessive amounts of grease may result in difficulty in assembling unit and incorrect selection of snap rings.




H7RA1110

- Use the special tool to press the journal bearing into the yoke until the snap ring groove is fully visible.
- Use the special tool to press the opposite side journal bearing into the yoke.


/!\ CAUTION

Be careful when pressing the journal bearings, as if they are pressed at an angle, the inside of the journal bearing will be damaged by the journal.



H7PS0200


Align the matchmark on the yoke and propeller shaft, and install the propeller shaft journal bearings in the method described in 2 and 3 above.



H7PS0210


ADJUSTMENT OF JOURNAL END PLAY

- Install the snap rings of the same thickness onto both sides of each yoke with the snap ring pliers.
- Press the bearing and journal into one side with the brass bar.



Measure the clearance shown in the illustration with a feeler gauge. If the clearance exceeds the standard value, adjust by changing the thickness of the snap


Standard value: 0 - 0.03 mm (0 - 0.0012 in.) or less



DRIVESHAFT

FRONT DRIVESHAFT ASSEMBLY

COMPONENTS (4WD) EIUC0360



- 1. Caliper assembly
- 2. Front speed sensor (Vehicle with ABS)
- 3. Stabilizer link connection
- 4. Tie rod end connection
- 5. Lower ball joint connection
- 6. Shock absorber lower mounting bolt
- 7. Upper ball joint mounting bolt
- 8. Knuckle and front hub assembly

- 9. Driveshaft assembly
- 10. Circlip

CAUTION

- *: Indicates parts which should be temporarily tightened, and then fully tightened with the vehicle on the ground in the unladen condition.
- N : Replace the parts with new one after removal.

TORQUE: Nm (kg·cm, lb·ft)

REMOVAL SERVICE POINTS


CALIPER ASSEMBLY REMOVAL

Secure the removed caliper assembly with wire so that it does not fall.

TIE ROD END DISCONNECTION

/!\ CAUTION

- Use the special tool (09568-34000) to loosen the nut only; do not remove it from the ball joint.
- 2. Tie the special tool with a cord not to let it fall off.



H7FA0510

LOWER BALL JOINT DISCONNECTION




/!\ CAUTION

Use the special tool to loosen the nut only; do not remove it from the lower ball joint.



NOTE

Do not remove it until disassembling the upper arm and knuckle.



H7FA0520

KNUCKLE AND FRONT HUB ASSEMBLY REMOVAL

Press down lower arm and remove upper knuckle towards you.


CAUTION

Do not damage upper ball joint nipple with upper arm.



NOTE

Pull the D.O.J. side of the driveshaft assembly out slightly from the front differential carrier.




H7FA0530

- Slightly back off driveshaft from knuckle. Remove lower ball joint and knuckle holding nut.
- Disconnect knuckle and lower ball joint.
- Remove knuckle and front hub assembly from driveshaft assembly.



CAUTION

Do not damage knuckle oil seals with driveshaft spline.




H7FA0540

DRIVESHAFT (LEFT SIDE) REMOVAL




/!\ CAUTION

When pulling the driveshaft out from the differential carrier, be careful that the spline part of the driveshaft does not damage the oil seal.







EIJA010A

INSPECTION EIUC0380

- Check the boot for damage or deterioration.
- Check the ball joint for operating condition and excessive looseness.
- Check the splines for wear or damage.
- Check the differential carrier oil seal (L.H.) for damaged.



S5DS008A

INSTALLATION SERVICE POINTS

DRIVESHAFT (LEFT SIDE)



- Do not damage the oil seal of the differential carrier by the driveshaft splines.
- Replace the circlip which is attached to the B.J side spline part with a new one.
- Check the quantity of oil in the differential carrier and fill if it is insufficient.


KNUCKLE AND FRONT HUB ASSEMBLY

Insert knuckle and front hub assembly to driveshaft.



/ CAUTION

Do not damage knuckle oil seal with driveshaft spline.



H7FA0560

- Assemble knuckle and lower ball joint and temporarily tighten slotted nut.
- Press up lower arm and lock upper ball joint onto upper arm.
- Tighten lower ball joint mounting nuts to specified torque.

SHOCK ABSORBER LOWER MOUNTING BOLT **INSTALLATION**

Insert the shock absorber lower mounting bolt from the rear of the vehicle.



NOTE


DO not insert from the front of the vehicle, or your may have trouble tightening the nut.

STABILIZER LINK INSTALLATION

Use an Allen key to tighten the nut while making sure that the stud on the stabilizer link does not turn as well.

FRONT DRIVESHAFT(G.I-A.C TYPE)

COMPONENTS EIUC0400



H7PS0340

REPAIR KITS

Kit name	Illustration	Contents
G.I. boot kit	O O O O O O O O O O O O O O O O O O O	 Circlip Snap ring G.I. boot G.I. boot band Boot band Grease
G.I. joint kit	V5DS010C	 Circlip G.I. case Snap ring Spider assembly G.I. boot G.I. boot band Boot band Grease
A.C. boot kit	9 0 0000 (V5DS010D	 Circlip Snap ring G.I. boot band Boot band Dynamic damper band Boot band A.C. boot Grease
A.C. joint and shaft kit	V5DS010E	 Circlip Snap ring G.I. boot band Boot bands Dynamic damper band A.C. boot band A.C. boot A.C. assembly Grease


DISASSEMBLY EIUC0410



- Do not disassemble the spider assembly.
- The driveshaft joint uses special grease. Do not substitute with another type of grease.
- The boot band should be replaced with a new one.
- 1. Remove the G.I. boot bands and pull the G.I. boot from the G.I. case.




Be careful not the damage the boot.



EIDA301A

2. Remove the snap ring and spider assembly from the driveshaft.




EIA9301B

- 3. Clean the spider assembly.
- 4. Remove the A.C. boot bands and pull out the G.I. boot and A.C. boot.



If the boot is to be reused, wrap tape around the driveshaft splines to protect the boot.




EIDA251D

INSPECTION AFTER DISASSEMBLY EIUC0420

- 1. Check the driveshaft spline part for wear or damage.
- Check for entry of water and/or foreign material into A.C.
- Check the spider assembly for roller rotation, wear or corrosion.

 Check the groove inside G.I. case for wear or corrosion



EIDA252A

REASSEMBLY EIUC0430

- 1. Wrap tape around the driveshaft splines (G.I. side) to prevent damage to the boots.
- 2. Apply grease to the driveshaft and install the boots. **Recommended lubricant**

A.C. boot grease: CENTURY

G.I. boot grease: ONE LUBER GKN

D.O.J. boot

B.J. boot






S5DS012A

3. Apply grease into the G.I. boot and install the boot.

G.I. boot grease gr. (oz): $200 \pm 10 (7.0 \pm 0.3)$

Tighten the G.I. boot band.




V5DS013C

- 5. Add to the A.C. as much specified grease as was wiped away at the time of inspection.
- 6. Install the boots.
- 7. Tighten the A.C. boot bands.
- To control the air in the G.I. boot, keep the specified distance between the boot bands when they are tightened.

CENTER BEARING AND INNER SHAFT

INNER SHAFT (4WD) EIUC0440

COMPONENTS



- 1. Caliper assembly
- 2. Shock absorber
- 3. Hub assembly, knuckle, driveshaft
- 4. Inner shaft
- 5. Circlip
- 6. Differential mounting bracket (RH)
- 7. Housing tube assembly

CAUTION


* Indicates parts which should be temporarily tightened, and then fully tightened with the vehicles on the ground in the unladen condition.

N : Replace the parts with new one after removal.

TORQUE: Nm (kg·m, lb·ft)

REMOVAL EIUC0450

- Remove the front hub and knuckle.
- 2. Remove the right driveshaft (RH).




H7FA0250

 Attach the special tools (09526-11001, 09526-11100) to the flange of the shaft, and pull the inner shaft out from the front differential carrier.



When pulling the inner shaft out from the front differential carrier, be careful that the spline part of the inner shaft does not damage the oil seal.



H7FA1226

INSPECTION EIMB2700

- 1. Check the inner shaft for bends.
- 2. Check the bearing for wear or damage.
- 3. Check the housing tube for crack.
- 4. Check the dust seal for crack or damaged.

INSTALLATION EIMB2750

- 1. Installation is the reverse of removal.
- 2. Using the special tools(09526-11001, 09526-11100), install the inner shaft to the differential carrier.


A CAUTION

Be careful not the damage the lip of the dust seal and oil seal.

DISASSEMBLY EIMB2800


REMOVAL OF BEARING

1) Bend the outside periphery of dust cover inward with a hammer.



H7FA0610

 After the special tool(09527-4A000) has been installed as shown, tighten the nut of the special tool until the portion "A" of the special tool touches the bearing outer race.




EIMB275A

3) Press out the inner shaft from the bearing.



Do not allow the inner shaft to drop.




H7FA0630

REASSEMBLY

EIMB2900

1. INSTALLATION OF DUST SEAL

Press-fit the new dust seal into the housing tube using the special tool(09216-21100) until it is flush with the housing tube end face.



EIMB380A


2. INSTALLATION OF DUST COVER

Using a steel pipe, force a new dust cover onto the inner shaft.

Steel pipe	mm (in.)
Overall length	50 (1.97)
Outside diameter	75 (2.95)
Wall thickness	4 (0.16)




After installing the dust cover, apply 5 gr. more than of the grease (LIG-2) on around rip.



EIMB290A

3. BEARING INSTALLATION

Use the special tool to press-fit the bearing onto the inner shaft.




H7FA0660

FRONT AXLE

FRONT HUB/KNUCKLE

COMPONENTS (2WD) EIUC0170



EIUC017A


REMOVAL EILB0150

CALIPER ASSEMBLY

- Remove the caliper assembly with the brake hose connected.
- Use wire to suspend the caliper assembly from the upper arm so that the caliper assembly won't fall.




Do not twist the brake hose.



AU51-06A

FRONT HUB ASSEMBLY

Remove the front hub assembly from the knuckle so that the outer bearing inner race doesn't fall.



ESRDS07C

INSPECTION EILB0160


- 1. Check the oil seal for cracks and damage.
- 2. Check the bearings for seizure and discoloration.
- 3. Check the front hub for cracks.
- Check grease in front hub.

INSTALLATION EIUC0200

 Pack entire inner hub wall with specified grease before installing front hub assembly to knuckle.

Specified grease:


LIG-2 (MS 511-7) or SUN LIGHT #2.



KIUB018A


2. WHEEL BEARING NUT

- a. After tightening the wheel bearing nut to 30Nm (300 kg·cm, 22.2 lb·ft), rotate the front hub and disc above 3 times to install the hub bearing securely.
- b. Loosen the wheel bearing nut to 0Nm (0 kg·cm, 0 lb·ft).
- c. Re-tighten the wheel bearing nut to 18 Nm (180 kg·cm, 13 lb·ft).



AU51-06D

d. Install the split pin. If the knuckle spindle hole and the hub bearing nut groove are not in alignment, turn the wheel bearing nut back within 30° maximum.




AU51-06E

3. GREASING HUB CAP

Fill cap with specified grease.


Specified grease:

LIG-2 (MS 511-7) or SUN LIGHT #2.



AU51-07A

COMPONENTS (4WD) EIUC0210




EIUC021A

REMOVAL SERVICE POINTS EIUC0220


LOCK NUT REMOVAL

Using the special tool (09518-4A000), remove the lock nut.



FRONT HUB ASSEMBLY REMOVAL

Do not drop the outer bearing inner race.



H7FA030A


KHPDS06A

INSTALLATION SERVICE POINTS EIUCO

LOCK HUT INSTALLATION

Using the special tool (09518-4A000), tighten the lock nut by the following procedures.


- 1. Tighten the lock nut to 13 20 Nm (130 200 kg·cm, 9.6 14.8 lb·ft), and then turn the front hub assembly to run in the bearings.
- 2. Loosen the nuts to 0 Nm (0 kg·cm, 0 lb·ft).
- 3. After re-tightening to 25 Nm (250 kg·cm, 18 lb·ft), loosen the lock nuts by approximately 30° 40°.



H7FA0310

LOCK WASHER INSTALLATION

Install the lock washer. If the hole position is not aligned with the lock nut, move it within a range of not more than 20° until the holes are aligned.




KHPD673A

HUB STARTING TORQUE AND WHEEL BEARING END PLAY ADJUSTMENT

 Use a spring balance to measure the hub starting torque as shown in the illustration.

Standard value:


1.1 - 1.6 Nm (0.5 - 16 kg·cm, 0.8 - 1.2 lb·ft)



KSRDS40A

- If the hub starting torque is not within the standard value, remove the lock washer and adjust by the following procedure.
 - 1) If the starting torque is lower than the standard value, tighten the lock nut.
 - 2) If the starting torque is higher than the standard value, loosen the lock nut.
- 3. Install a dial gauge as shown in the illustration, and then move the hub in the axial direction and measure how far the front wheel bearing moves.

Standard value: 0.05 mm (0.002 in.) or less




H7FA0340

- 4. If the distance exceeds the standard value, remove the lock washer and tighten the lock nut.
- 5. If adjustment is not possible, disassemble the hub and inspect each part.

DISASSEMBLY AND REASSEMBLY EIUC0240

COMPONENTS



EIUC024A

DISASSEMBLY


EILB0190

BRAKE DISC

 Make the matchmark on the brake disc and front hub, and then separate the front hub and brake disc, if necessary.




When mounting the disc in vice, fix copper or aluminum board to the jaws of it.



ESRDS69A

2. Using the special tool (09517-21400), drive out the inner and outer bearing outer races by tapping them equally.




ESRDS71A

REASSEMBLY EIUC0260

1. Press-fit the inner bearing outer race and outer bearing outer race.

NOTE

The bearing inner race and baring outer race should be replaced as an assembly.




EIUC026A

2. Press-fit new oil seal into the front hub, until it is flush with the front hub end face.

KNUCKLE (2WD) EIUC0270

COMPONENTS



Removal steps

- 1. Caliper assembly
- 2. Front speed sensor <vehicles with ABS>
- 3. Hub assembly
- 4. Dust shield
- 5. Clamp
- 6. Stabilizer link
- 7. Shock absorber lower mounting bolt
- 8. Tie rod end connection
- 9. Lower arm connection
- 10. Upper arm connection
- 11. Knuckle

CAUTION


*: Indicates parts which should be temporarily tigntened, and then fully tightened with the vehicles on the ground in the unladen condition.

N : Replace the split pin with new one after removal.

TORQUE: Nm (kg·cm, lb·ft)

REMOVAL EIUC0280

1. Remove the front hub assembly from the knuckle together with the outer bearing and washer.




EIUC028A

Disconnect the tie rod assembly and knuckle with the special tool.




Loosen nut but do not remove.



AU51-11A

3. Disconnect the upper/lower ball joint from the knuckle with the special tool. (09544-43000)



AU51-11B

INSPECTION EILBO230

- 1. Check the knuckle for cracks and deformation.
- 2. Check the knuckle spindle for wear and damage.


INSTALLATION EIUC0300

- 1. Insert the shock absorber lower mounting bolt in the front of the vehicle.
- 2. Tighten the components below to the specified torque

Items	Torque Nm (kg·cm, lb·ft)
Knuckle to tie rod end mounting nut	35 - 45 (350 - 450, 26 - 33)
Upper/lower arm ball joint to knuckle mounting	120 - 180 (1200 - 1800, 88 - 133)
Lower arm to shock absorber lower mounting bolt	70 - 95 (700 - 950, 52 - 70)

KNUCKLE (4WD) EIUC0310

COMPONENTS



Removal steps

- 1. Caliper assembly
- 2. Front speed sensor (Vehicle with ABS)
- 3. Hub assembly
- 4. Dust shield
- 5. Stabilizer link connection
- 6. Tie rod end connection
- 7. Shock absorber lower mounting bolt
- 8. Upper ball joint mounting bolt

- 9. Lower ball joint connection
- 10. Knuckle
- 11. Upper ball joint

CAUTION

*: Indicates parts which should be temporarily tightened, and then fully tightened with the vehicle on the ground in the unladen condition.

TORQUE: Nm (kg·cm, lb·ft)

REMOVAL SERVICE POINTS EIUC0320


1. CALIPER ASSEMBLY REMOVAL

Secure the removed caliper assembly with wire so that it does not fall.

2. TIE ROD END DISCONNECTION

(CAUTION

- Use the special tool to loosen the nut only; do not remove it from the ball joint.
- Tie the special tool with a cord not to let it fall



H7FA0370


3. LOWER BALL JOINT DISCONNECTION

CAUTION

The nut should be loosened only, not removed.

NOTE

Leave nut on lower ball joint until knuckle and upper arm are disconnected.




H7FA0380

4. KNUCKLE REMOVAL

 Press down lower arm and remove upper knuckle toward you.



Do not damage upper ball joint nipple with upper arm.




H7FA0390

- 2) Slightly back off driveshaft from knuckle. Remove lower ball joint and knuckle holding nut.
- 3) Disconnect knuckle and lower ball joint.
- 4) Remove knuckle and front hub assembly from driveshaft assembly.

/ CAUTION

Do not damage knuckle oil seals with driveshaft spline.




H7FA0400

5. UPPER BALL JOINT DISCONNECTION

(CAUTION

The nut should be loosened only, not removed.



H7FA0410


INSTALLATION SERVICE POINTS EIUC0330

KNUCKLE INSTALLATION

- Install upper ball joint on knuckle. Temporarily tighten slotted nut.
- Insert knuckle into driveshaft.


/ CAUTION

Do not damage oil seal with driveshaft spline.



H7FA0420

- Assemble knuckle and lower ball joint. Temporarily tighten slotted nut.
- Push up lower arm to lock upper ball joint to upper arm.
- Tighten upper and lower ball joint connecting nut to specified torque.



H7FA0430

SHOCK ABSORBER LOWER MOUNTING BOLT **INSTALLATION**


Insert the shock absorber lower mounting bolt from the rear of the vehicle.



Do not insert from the front of the vehicle, or you may have trouble tightening the nut.

STABILIZER LINK INSTALLATION


Use an Allen key to tighten the nut while making sure that the stud on the stabilizer link does not turn as well.



H7FA0440

KNUCKLE EIUC0340

COMPONENTS



EHPDS12B


DISASSEMBLY

- Remove the oil seal and take out the spacer.
- Drive out the needle bearing by tapping the needles uniformly.



/!\ CAUTION

Once removed, the needle bearing must not be reused.



H7FA0460


REASSEMBLY EIMB3800

Use the special tools to press-fit the needle bearing until it is flush with the knuckle end face.




CAUTION

Care to prevent driving the needle bearing too far




KIMB200A

2. Apply multi-purpose grease(LIG-2 or equivalent) to the contact surface of the spacer and install the spacer to knuckle.



H7FA0480


3. Use the special tools(09500-11000, 09542-4A000) to press-fit the new oil seal until it is flush with the knuckle end face.



H7FA0490

FREE WHEEL HUB ASSEMBLY

COMPONENTS EIUC0500



EIUB040A


DESCRIPTION EIUCO510

Auto vacuum type free wheel hub assembly is actuated by vacuum which is generated in the surge tank or vacuum pump. When the solenoid valve energized, it allows the vacuum from the vacuum tank to act on the free wheel hub.

The vacuum pull the piston and clutch ring toward the front hub assembly to engage the clutch ring with the inner drive gear. This results in the power flow to continue from the CV joint to the front hub via free wheel hub (Locked Mode). When the solenoid value de-energized the vacuum no longer acts on the free wheel hub. Therefore the return spring inside the free wheel hub returns the piston and clutch ring to their original position and disengages the

power flow from the C.V. joint to the free wheel hub (Free Mode).

SCHEMATIC DRAWING EIUC0520




EIUB042A

SOLENOID VALVE INSPECTION EIUC052



When disconnecting the vacuum hoses, make identification marks on it so it can be reconnected to its original position.


- Disconnect the vacuum hoses from the solenoid valve.
- 2. Detach the harness connector.



EIUB043A


- 3. Connect the vacuum pump to the nipple which was connected to the vacuum tank hose (Blue stripe).
- 4. Apply vacuum and check when the voltage is applied or disconnected to the solenoid valve.

Battery Voltage	Normal condition	
When disconnected	Vacuum is maintained	
When applied	Vacuum is released	



H7FA1225

5. Connect the vacuum pump to the nipple which was connected to the free wheel hub hose (white stripe)



H7FA1225

6. Apply the vacuum and check when the voltage is applied or disconnected to the solenoid valve.

Battery Voltage	Nipple to at- mosphere	Normal condition
When disconnected	Plugged	Vacuum is maintained
When disconnected	Opened	Vacuum is released
When connected		Vacuum is released

REAR AXLE


REAR AXLE ASSEMBLY EIUC0540

REMOVAL AND INSTALLATION

14. Lower arm mounting bolt


TORQUE: Nm (kg·cm, lb·ft)

COMPONENTS (WITH COIL SPRING TYPE)



in the unladen condition.

COMPONENTS (WITH LEAF SPRING TYPE)



- 1. Brake drum
- 2. Parking brake cable, speed sensor (Vehicles with ABS) mounting bolt
- 3. Parking brake cable connection
- 4. Speed sensor connection (Vehicles with ABS)
- 5. Brake tube connection
- 6. Load sensing proportioning valve connection
- 7. Propeller shaft connection
- 8. Shock absorber connection
- 9. U-bolt seat
- 10. Spring pad, lower
- 11. U-bolts
- 12. Bump stopper

- 13. Clamp
- 14. Spring pad, upper
- 15. Shackle assembly
- 16. Axle assembly

CAUTION

- *: Indicates parts which should be temporarily tightened, and then fully tightened with the vehicle on the ground in the unladen condition.
- N: Replace the parts with new one after removal.

TORQUE: Nm (kg-cm, lb-ft)

SERVICE INSPECTION PROCEDURE

AXLE SHAFT END PLAY CHECK

Measure the axle shaft end play using a dial indicator.


Standard value

CBS (Conventional Brake System):

0.05 - 0.20 mm (0.0093 - 0.0079 in.)

ABS (Anti-lock Brake System):

0 - 0.25 mm (0 - 0.0098 in.)



KHPDS47A

If the axle shaft end play exceeds the standard value, replace the bearing with a new one.

GEAR OIL LEVEL CHECK

- Remove the filler plug and check the quantity of oil in the differential carrier.
- It is enough if oil is applied until the filler plug.


Specified gear oil: Hipoid gear oil

Conventional differential

- General zone (-30°C +30°C): API GL-4 class (SAE90)
- Severe heat zone (+30°C MIN.): API GL-4 class (SAE140)
- Severe frigid zone (-30°C MAX.): API GL-5 class (SAE80)

With LSD:

Mobil Korea infilrex 33 or equivalent (API GL-4 class SAE90)




FIJA010A

REMOVAL

- Remove the brake drum.
- 2. Remove the parking brake cable and speed sensor.
- 3. Disconnect the brake tube connection.
- Disconnect the load sensing proportioning valve connection.
- Disconnect the propeller shaft from the companion
- Remove the stabilizer bar mounting clamp (Coil spring
- Remove the lateral rod (Coil spring type)
- Remove the shock absorber assembly.



Support the rear axle housing with rigid jack before removing the shock absorber mounting nut.



H7RA0600

Remove the lower arm and upper control arm assembly (Coil spring type)



/!\ CAUTION

Be careful not to drop the axle assembly

INSTALLATION EIUC0570


- 1. Installation is the reverse of removal.
- 2. Tighten the parts with the specified torque as follows:

Items	Specified torque Nm(kg·cm, lb·ft)
Wheel nut mounting	120 - 140 (1200 - 1400, 88 - 103.6)
Brake caliper mounting bolt	80 - 100 (800 - 1000, 58 - 73)
Rear shock absorber lower mounting nut	65 - 85 (650 - 850, 48 - 63)
Rear upper control arm mounting	180 - 200 (1800 - 2000, 130 - 144)
Rear lower arm mounting	180 - 200 (1800 - 2000, 130 - 144)
Lateral rod mounting nut (Rear axle side)	150 - 170 (1500 - 1700, 108 - 122)
Lateral rod mounting (Frame side)	180 - 200 (1800 - 2000, 130 - 144)

REAR AXLE SHAFT ASSEMBLY

COMPONENTS

EIMB5100



- 1. Brake drum/Disc
- 2. Shoe-lining assembly
- 3. Rear axle housing
- 4. Axle shaft assembly
- 5. O-ring
- 6. Oil seal


II : Replace the parts with new one after removal.

EHPDS46A

REMOVAL


EIMB5200

- 1. Remove the brake drum.
- 2. Remove the shoe-lining assembly.
- 3. Remove the parking brake cable and speed sensor cable.
- Disconnect the brake hose and tube connection.
- 5. Remove the rear axle housing and axle shaft mounting bolt.
- Using the special tools(09526-11001, 09526-11100), remove the axle shaft from the rear axle housing.



H7RA0540


Using the special tool(09526-11100), remove the oil seal.



H7RA0550

INSTALLATION EIMB5300

- 1. Installation is the reverse of removal.
- 2. Apply grease to the oil seal lip.
- 3. Using the special tools(09500-11000, 09532-11500), install the oil seal.



H7RA0560

- 4. After installing the axle shaft, bleed the brake line.
- 5. Adjust the parking brake lever stroke.

B. Historianing itseriado 10 Offise i 11 Scattic externs c (第:社会社会等 itse gents with

TOTAL THE MAN BUILDING

Marine 1997 and Control of Marinese Control of Contro

THE KIEWBERREN

्रे के दृश्य गर्भ अवस्थिति


erce province of a profit to a remaining will remain all

rein product

Salahan da karangan da kar Banggarangan da karangan d

DISASSEMBLY AND REASSEMBLY EIMB5400

COMPONENTS



- 1.
- 2. Rotor (Vehicles with ABS)
- Retainer
- Axle shaft
- 5. Bearing case
- Backing plate
- 7. Outer bearing inner race
- Dust cover
- Inner bearing inner race
- 10. Oil seal
- 11. Bearing outer race


N : Replace the parts with new one after removal.

TORQUE: Nm (kg·m, lb·ft)

EIMB620A

DISASSEMBLY

- Remove the snap ring.
- Remove the retainer bolt from the backing plate.



Apply gummed cloth tape around the edge of the bearing case for protection.


4. As shown in the figure, fix the axle shaft and shave off with grinder a point of its circumference locally until the wall thickness on the side of axle shaft of retainer becomes approximately 1.0-1.5mm (0.039-0.059in.).



/!\ CAUTION

Be careful not to damage the bearing case and the axle shaft.

EHPDS33B




FIMB630A

5. Cut in with a chisel the place where the retainer ring has been shaven.



Be careful not to damage the axle shaft.




H7RA1140

Install the special tool(09526-43200) and then separate the bearing case and backing plate from the axle shaft.


NOTE

Secure the plate of the special tool(09526-43200) and bearing case with the bolts (length: 100mm or longer).



EIMB550A

 Using the special tool(09527-4A000), remove the outer bearing inner race from the axle shaft.




EIMB550B

INSPECTION EIMB5600

- 1. Check the axle shaft spline part for wear or damage.
- 2. Check the backing plate for deformation and damage.
- 3. Check the bearing for seizure and discoloration.
- Check the axle shaft for bend, wear or damage.

REASSEMBLY EIMB5700

1. Press-fit bearing outer race to the bearing case.



H7RA0750

Apply multi-purpose grease to the roller surface and ends of the bearing inner race and fit it to the bearing case.


Specified grease: CENTOPLEX 278 (MS511-7)

3. Press-fit the oil seal into the bearing case until it is flush with the face of the bearing case using the special tool(09535-11000).




Apply multi-purpose grease to the lip of the oil seal.

Specified grease: CENTOPLEX 278 (MS511-7)




H7RA1260

- 4. Install the backing plate.
- 5. Using the special tool(09545-21100), press-fit the bearing case, inner bearing inner race, and outer bearing inner race to the axle shaft.



H7RA0730

6. Using the special tool(09545-21100), press-fit the retainer at the initial force of 5,000kg or more and at the final force of 10,000-11,000kg.



EHPDS51A


7. After installing the snap ring, measure the clearance(A) between the snap ring and the retainer.

Standard value(A): 0-0.166mm (0-0.0065in.)



If the clearance exceeds the standard value, change the snap ring so that the clearance is at the standard value.

Thickness of snap ring (mm)	Identification color
2.17	Blue
2.01	Violet
1.85	Red
1.69	Yellow
1.53	-




EHPDS48A

DIFFERENTIAL CARRIER ASSEMBLY

FRONT DIFFERENTIAL CARRIER

COMPONENTS

EIUC0640



Removal steps

- 1. Driveshaft
- 2. Circlip
- 3. Inner shaft
- 4. Circlip
- 5. Front propeller shaft connection
- 6. Differential mounting bracket (L.H.)
- 7. Front differential, housing tube, differential bracket (R.H.)

- 8. Differential support bracket
- 9. Differential mount insulator assembly
- 10. Differential mounting bracket (R.H.)
- 11. Housing tube
- 12. Front differential carrier assembly

N : Replace the parts with new one after removal.


TORQUE: Nm (kg·cm, lb·ft)

REMOVAL

- Remove the hub and knuckle (Refer to "Front hub/knuckle" for the detail).
- Remove the driveshaft.



When removing the driveshaft, be careful not to damage the differential carrier oil seal by interference of spline part.




KHPDS13A

- Drain oil.
- Remove the inner shaft.



/!\ CAUTION

- Support the differential carrier with a jack to prevent it from falling.
- Use the special tools(09526-11001, 09526-11100) to remove the inner shaft easily.




H7FA1226

Remove the front propeller shaft.



Make matchmark on the flange yoke and differential companian flange to avoid any mistake when installing them again.




FIMBOSOA

Remove the differential carrier.

INSPECTION BEFORE DISASSEMBLY EIUC0660

Mount the differential carrier on the special tool(09517-43401).



H7FS0600

DRIVE GEAR BACKLASH

Fix the drive gear so it cannot move and measure the drive gear backlash with a dial indicator.



NOTE

Measure at four points or more on the circumference of the drive gear.

Standard value: 0.11-0.16mm (0.0043-0.0063in.)



H7FA0690

If the backlash is beyond the standard value, adjust it using the side bearing spacers.

NOTE

After adjustment, inspect the contact of the drive gear.

DRIVE GEAR RUNOUT

Check the back-face lash as follows:

Place a dial gauge on the back-face of the drive gear and measure the runout.

Limit: 0.05 mm (0.0020 in.)

- If the runout is beyond the limit, check that there are no foreign substances between the drive gear and differential case and, that the bolts fixing the drive gear are not loose.
- If nothing is wrong in check (2), adjust the drive gear depth and remeasure.

NOTE

If these adjustments are impossible, replace the case or install a new drive gear/drive pinion as a set.



H7FA0700

DIFFERENTIAL GEAR BACKLASH


Fix the side gear with a wedge so it cannot move and measure the differential gear backlash with a dial indicator on the pinion gear.

| ∪ NOTE

Take the measurements at two places (4 places for LSD) on the pinion gear.

Standard value: 0-0.076 mm (0-0.003 in.)

Limit: 0.2 mm (0.008 in.)



A7FA0710

If the backlash exceeds the limit, adjust using side bearing spacers.


NOTE

If adjustment is impossible, replace the side gear and pinion gears as a set.

DRIVE GEAR TOOTH CONTACT

Check the drive gear tooth contact by following the steps below:

Apply the same amount of machine blue slightly to both surfaces of the drive gear teeth.



H7FA0720


Insert a brass rod between the differential carrier and the differential case, and then rotate the companion flange by hand (once in the normal direction, and then once in the reverse direction) while applying a load to the drive gear so that some torque (approximately 25-30 kg·cm) is applied to the drive pinion.



/!\ CAUTION

If the drive gear is rotated too much, the tooth contact pattern will become unclear and difficult to check.


3. Check the tooth contact pattern.



EIJA001B

Standard tooth contact pattern


- 1. Narrow tooth side
- 2. Drive-side tooth surface (the side receiving power during acceleration)
- 3. Wide tooth side
- 4. Coast-side tooth surface (the side receiving power during coast-down)




EIJA0011

Problem Solution

Tooth contact pattern resulting from excessive pinion height



EIJA0012




EIJA0013

The drive pinion is positioned too far from the center of the drive gear.

Increase the thickness of the pinion height adjusting shim, and position the drive pinion closer to the center of the drive gear.


Also, for backlash adjustment, reposition the drive gear further from the drive pinion.

Tooth contact pattern resulting from insufficient pinion height



EIJA0014

The drive pinion is positioned too close to the center of the drive gear.



EIJA001

Decrease the thickness of the pinion height adjusting shim, and position the drive pinion further from the center of the drive gear.

Also, for backlash adjustment, reposition the drive gear closer to the drive pinion.


NOTE

- Tooth contact pattern is a method for judging the result of the adjustment of drive pinion height and final drive gear backlash. The adjustment of drive pinion height and final drive gear backlash should be repeated until the tooth contact patterns are similar to the standard tooth contact pattern.
- When you cannot obtain a correct pattern, the drive gear and drive pinion have exceeded their limits. Both gears should be replaced as a set.

INSTALLATION EIMB6100

- 1. Installation is the reverse of removal.
- Align the matchmark on the flange yoke and the companion flange.

Tighten the propeller shaft and the front differential carrier.




EIMB080A

DISASSEMBLY

EIMB6200

COMPONENTS



Disassembly steps

- 1. Cover
- 2. Bearing cap
- 3. Differential case assembly
- 4. Side bearing spacer
- 5. Side bearing outer race
- 6. Side bearing innter race
- 7. Drive gear
- 8. Lock pin
- 9. Pinion shaft
- 10. Pinion gear11. Pinion washer
- 12. Side gear
- 13. Side gear spacer
- 14. Differential case
- 15. Self-locking nut
- 16. Washer
- 17. Drive pinion assembly
- 18. Drive pinion

- 19. Drive pinion (for pinion height adjustment)
- 20. Drive pinion front bearing inner race
- 21. Drive pinion spacer
- 22. Drive pinion rear shim (for turning torque adjustment)
- 23. Companion flange
- 24. Oil seal
- 25. Drive pinion rear bearing inner race
- 26. Drive pinion rear bearing outer race
- 27. Drive pinion front bearing outer race
- 28. Oil seal
- 29. Gear carrier
- 30. Plug cover
- 31. Vent plug

: Replace the parts with new one after removal.

TORQUE: Nm (kg·cm, lb·ft)

DISASSEMBLY

EIMBEROO

REMOVAL OF THE DIFFERENTIAL CASE ASSEM-




/ CAUTION

Remove the differential case assembly slowly and carefully. Be careful so that the side bearing outer race is not dropped.



NOTE

Keep the right and left side bearings separate so that they are not mixed during reassembly.



H7FA0740


REMOVAL OF THE SIDE BEARING INNER RACES

Fit the nut on top of the differential case, and then use the special tool(09517-43001) to remove the side bearing inner race.



NOTE


Attach the prongs of the special tool to the inner race of the side bearing through the notched section in the differential case.



H7FA0750


REMOVAL OF DRIVE GEAR

- Make the matchmarks to the differential case and the drive gear.
- Loosen the drive gear attaching bolts in diagonal sequence to remove the drive gear.



A7FA0760

REMOVAL OF LOCK PIN (FOR CONVENTIONAL DIFFERENTIAL)



H7FA0770

REMOVAL OF SELF-LOCKING NUT



H7RA1100

REMOVAL OF DRIVE PINION


Make the matchmarks to the drive pinion and companion flange.



/!\ CAUTION


Matchmarks should not be made to the contact surfaces of the companion flange and the propeller shaft.

Drive out the drive pinion together with the drive pinion spacer and drive pinion front shims.




H7FA0790

7. REMOVAL OF DRIVE PINION REAR BEARING IN-NER RACE




H7RA1090

8. REMOVAL OF OIL SEAL / DRIVE PINION FRONT BEARING INNER RACE / DRIVE PINION FRONT BEARING OUTER RACE



KIMB520D

9. REMOVAL OF DRIVE PINION REAR BEARING OUTER RACE



KIMB520E


INSPECTION EIJB0490

- 1. Check the companion flange for wear or damage.
- 2. Check the bearings for wear or discoloration.
- 3. Check the gear carrier for cracks.
- 4. Check the drive pinion and drive gear for wear or cracks.
- 5. Check the side gears, pinion gears and pinion shaft for wear or damage.
- 6. Check the side gear spline for wear or damage.

REASSEMBLY

EIUC0710

COMPONENTS



- 2. Plug cover
- 3. Gear carrier
- 4. Oil seal
- 5. Drive pinion front bearing outer race
- 6. Drive pinion rear bearing outer race
- Pinion height adjustment
- 7. Drive pinion
- 8. Drive pinion front shim (for pinion height adjustment)
- 9. Drive pinion front bearing inner race
- 10. Drive pinion rear bearing inner race
- 11. Oil seal
- 12. Drive pinion rear shim (for turning torque adjustment)
- 13. Drive pinion spacer
- 14. Drive pinion assembly
- 15. Companion flange
- 16. Washer
- 17. Self-locking nut

- 20. Side gear
- 21. Pinion washer
- 22. Pinion gear
- Differential gear backlash adjustment
- 23. Pinion shaft
- 24. Lock pin
- 25. Drive gear
- 26. Side bearing innter race
- 27. Side bearing outer race
- 28. Side bearing adjustment spacer
- Drive gear backlash adjustment
- 29. Differential case assembly
- 30. Bearing cap
- 31. Cover


N : Replace the parts with new one after removal.

TORQUE: Nm (kg·cm, lb·ft)

LUBRICATION, SEALING AND ADHESIVE

POINTS EIMB6600


COMPONENTS



REASSEMBLY

EIMB6700

PRESS-FITTING OF IL SEAL




EIMB670A

2. DRIVE PINION FRONT BEARING OUTER RACE IN-STALLATION

CAUTION

When press-fitting the outer race, do not incline it.




H7FA0860

 DRIVE PINION REAR BEARING OUTER RACE IN-STALLATION

(CAUTION

When press-fitting the outer race, do not incline it.



H7FA0870


4. ADJUSTMENT OF PINION HEIGHT

Adjustment the drive pinion height by the following procedure.

1) Install the special tool, drive pinion front and rear bearing inner races to the gear carrier.

(CAUTION

Apply multipurpose grease to the washer of the special tool(09500-43131).



EIMB670B

 Tighten the nut of the special tool(09500-43131) slowly until the standard value of drive pinion turning torque(without oil seal) is obtained.




EIMB670C

Bearing division	Bearing lubrication	Rotation torque
New	None (With anti-rust agent)	0.5 - 0.7Nm
New or reusing	Gear oil applied	0.3 - 0.4Nm

NOTE

- Gradually tighten the nut of the special tool while checking the drive pinion turning torque.
- Because the special tool cannot be turned one rotation, turn it several times within the range that it can be turned. After obtaining smooth bearing operation, measure the rotation torque.




KIMB540A

 Position the special tool in the side bearing seat of the gear carrier and select a drive pinion rear shim of a thickness which corresponds to the gap between the special tools.


NOTE

- Clean the side bearing seat thoroughly. When
 positioning the special tool, confirm that the
 cut-out sections of the special tool touch the side
 bearing seat very closely.
- When selecting the drive pinion rear shims, use the fewest number of shims necessary.



KHPD736A

 Fit the selected drive pinion rear shim(s) to the drive pinion, and press-fit the drive pinion rear bearing inner race using the special tool(09535-11000).



AIJA030A


7. ADJUSTMENT OF DRIVE PINION PRELOAD Adjust the drive pinion turning torque according to the following procedures:

1) Fit the drive pinion front shim(s) between the drive pinion spacer and the drive pinion front bearing inner race.

₩ NOTE

Do not install the oil seal.

2) Tighten the companion flange self-locking nut to the specified torque using the special tool.




H7FA0930

 Measure the drive pinion turning torque (without the oil seal) using the special tool.

Standard value:

0.15-0.25Nm (1.5-2.5kg·cm, 0.12-0.18lb·ft)



H7FA0940

4) If the drive pinion turning torque is not within the range of the standard value, adjust the turning torque by replacing the drive pinion front shim(s) or the drive pinion spacer.


NOTE

When selecting the drive pinion front shim pack use the minimum number of shims.

5) Remove the companion flange and drive pinion once again.Insert the oil seal into the gear carrier front lip


using the special tool(09216-21300).

Apply multipurpose grease to the oil seal lip.



H7FA0960

6) Install the drive pinion assembly, shim packs and companion flange with matchmarks properly aligned, and tighten the companion flange self-locking nut to the specified torque using the special tool(09517-21700).




H7FA0970

7) Measure the drive pinion turning torque using the special tool(09532-11600).

Standard value:

0.35-0.45Nm (3.5-4.5kg·cm, 0.26-0.33lb·ft)



H7FA0980


- 8) If it is beyond the standard value, verify the torque of the companion flange self-locking nut or the fit of the oil seal.
- 8. ADJUSTMENT OF DIFFERENTIAL GEAR BACK-LASH

Adjust the differential gear backlash according to the following procedures :

- Assemble the side gears, side gear spacers, pinion gears, and pinion washers into the differential case.
- 2) Temporarily install the pinion shaft.

NOTE

Do not install the lock pin yet.



H7F40990


Insert a wedge in the side gear and measure the differential gear backlash with a dial indicator on the pinion gear.

NOTE

Measure both pinion gears separately.

Standard value: 0-0.076 mm (0-0.0003 in.)

Limit: 0.2 mm (0.008 in.)



A7FA1000


- If the differential gear backlash exceeds the limit, adjust the backlash by selecting thicker side gear thrust spacers.
- 5) Measure the differential gear backlash once again, and confirm that it is within the limit.

NOTE

- After adjustment, check that the backlash is within the limit and the differential gear rotates smoothly.
- When adjustment is impossible, replace the side gear and the pinion gear as a set.

9. INSTALLATION OF THE LOCK PIN


- Align the pinion shaft lock pin hole with the differential case lock pin hole, and drive in the lock pin.
- 2) Fix the lock pin in place by staking two points around the lock pin hole with a punch.



H7FA1010

10. INSTALLATION OF THE DRIVE GEAR


- 1) Clean the drive gear attaching bolts.
- Remove the adhesive on the threaded holes of the drive gear use a tap (M10 x 1.25), and then clean the threaded holes with compressed air.



H7FA1020

3) Apply the specified adhesive to the threaded holes of the drive gear.


Specified adhesive: LOCTITE #262 or equivalent



H7FA1030

4) Install the drive gear in the differential case with the matchmarks properly aligned. Tighten the bolts to the specified torque in a diagonal sequence.

11. PRESS THE SIDE BEARING INNER RACE




EIMB670D

- 12. ADJUSTMENT OF FINAL DRIVE GEAR BACKLASH Adjust the final drive gear backlash according to the following procedures:
 - Install side bearing spacers which are thinner than those removed, to the side bearing outer races, and then mount the differential case assembly into the gear carrier.




Select side bearing spacers with the same thickness for both the drive pinion side and the drive gear side.




H7FA1050

2) Push the differential case to one side, and measure the clearance between the gear carrier and the side bearing with a feeler gauge.



H7FA1060

3) Select two pairs of spacers which correspond to the value calculated according to the expression in the illustration. Install one pair each to the drive pinion side and the drive gear side.




A7FA1070

4) Install the side bearing spacers and differential case assembly, as shown in the illustration, to the gear carrier.




H7FA1080

5) Tap the side bearing spacers with a brass bar to fit them to the side bearing outer race.



H7FA1090

6) Align the matchmarks on the gear carrier and the bearing cap and tighten the bearing cap.



H7FA1100

7) With the drive pinion locked in place, measure the final drive gear backlash with a dial indicator on the drive gear.

NOTE

Measure at four points or more on the circumference of the drive gear.

Standard value: 0.11-0.16mm (0.0043-0.0063in.)



H7FA1110

8) Change the side bearing spacers as illustrated and then adjust the final drive gear backlash between the drive gear and the drive pinion.

NOTE

When increasing the number of side bearing spacers, use the same number for each and as few as possible.

Thicker spacer

Thicker spacer

Thicker spacer

Thicker spacer

If backlash is too large

A7FA1120

- 9) Check the drive gear and drive pinion for tooth contact. If poor contact is evident, adjust again.
- 10) Measure the drive gear runout at the shoulder on the reverse side of the drive gear.

Limit: 0.05 mm (0.002 in.)




H7FA1130


11) If the drive gear runout exceeds the limit, reinstall by changing the position of the drive gear and differential case, and remeasure.

REAR DIFFERENTIAL CARRIER

COMPONENTS

EIUC0740





Removal steps

- 1. Brake tube connection
- 2. Brake drum (2WD)
- 3. Parking brake attaching bolt
- 4. Parking brake cable connection
- 5. Rear axle shaft
- 6. Propeller shaft connection
- 7. Stabilizer bar clamp
- 8. Dynamic dumper
- 9. Differential carrier

TORQUE: Nm (kg·cm, lb·ft)

EIUB065A


REMOVAL

- Drain the differential gear oil.
- Remove the rear brake drum.
- 3. Remove the parking brake cable attaching bolt.
- Remove the brake tube connection.
- Pull out the right and left axle shaft using the special tools(09526-11001, 09526-11000) after removing the coupling nuts.



/!\ CAUTION

Be careful not to damage the oil seal when pulling axle shaft.



H7RA0870

Remove the flange yoke of the rear propeller shaft from the companion flange of the differential carrier.




/!\ CAUTION

Suspend the propeller shaft from the body with wire, etc.

Remove the attaching nuts and strike the lower part of differential carrier assembly with a piece of times several times to loosen, then remove the differential carrier assembly.




Use care not to strike the companion flange.



EIMB660A

INSPECTION BEFORE DISASSEMBLY EIUC0760

Secure the special tool(09517-43101) and install the differential carrier assembly with the attachment. Then carry out the following inspection.



H7RA1070


- FINAL DRIVE GEAR BACKLASH Check the final drive gear backlash by the following procedure.
 - Place the drive pinion and move the drive gear to check backlash is within the standard range.



Measure at 4 points on the gear periphery.

Standard value

0.01-0.16 mm (0.0043-0.0063 in.)




AU52-23B

Adjust with the side bearing nuts if backlash values are not within standard range.




After adjusting, check the state of the final drive gear's tooth contact.



KHPD019A

- DRIVE GEAR RUNOUT Check the back-face lash as follows:
 - Place a dial gauge on the back-face of the drive gear and measure the runout.

Limit: 0.05mm (0.0020in.)



AU52-32A

2) If the runout is beyond the limit, check that there are no foreign substances between the drive gear and differential case and, that the bolts fixing the drive gear are not loose.


3. DIFFERENTIAL GEAR BACKLASH

 Fix the side gear with a wedge so it cannot move and measure the differential gear backlash with a dial indicator on the pinion gear.

NOTE

Take the measurements at two places on the pinion gear.

Standard value: 0.01-0.076 mm (0.0004-0.003 in.) Limit: 0.2 mm (0.008 in.)




A7FA0710

2) If the backlash exceeds the limit, adjust using side bearing spacers.

NOTE

If adjustment is impossible, replace the side gear and pinion gears as a set.

- 4. FINAL DRIVE GEAR TOOTH CONTACT Check the final drive gear tooth contact by following the steps below:
 - 1) Apply the same amount of machine blue slightly to both surfaces of the drive gear teeth.




AU52-24B

2) Insert a brass rod between the differential carrier and the differential case, and then rotate the companion flange by hand (once in the normal direction, and then once in the reverse direction) while applying a load to the drive gear so that some torque (approximately 25-30kg cm) is applied to the drive pinion.

(CAUTION


If the drive gear is rotated too much, the tooth contact pattern will become unclear and difficult to check. 3) Check the tooth contact pattern.



EIJA001B

Standard tooth contact pattern


- 1. Narrow tooth side
- 2. Drive-side tooth surface (the side receiving power during acceleration)
- 3. Wide tooth side
- Coast-side tooth surface (the side receiving power during coast-down)



EIJA0011

Problem Solution

Tooth contact pattern resulting from excessive pinion height



EIJA0012

3


EIJA0013

The drive pinion is positioned too far from the center of the drive gear.

Increase the thickness of the pinion height adjusting shim, and position the drive pinion closer to the center of the drive gear.


Also, for backlash adjustment, reposition the drive gear further from the drive pinion.

Tooth contact pattern resulting from insufficient pinion height



FIJA0014

The drive pinion is positioned too close to the center of the drive gear.



EIJA0015

Decrease the thickness of the pinion height adjusting shim, and position the drive pinion further from the center of the drive gear.

Also, for backlash adjustment, reposition the drive gear closer to the drive pinion.

NOTE

- Tooth contact pattern is a method for judging the result of the adjustment of drive pinion height and final drive gear backlash. The adjustment of drive pinion height and final drive gear backlash should be repeated until the tooth contact patterns are similar to the standard tooth contact pattern.
- When you cannot obtain a correct pattern, the drive gear and drive pinion have exceeded their limits. Both gears should be replaced as a set.

INSTALLATION FILICOTTO

1. DIFFERENTIAL CARRIER ASSEMBLY

Apply specified sealant to axle housing flange surface, and install the differential carrier assembly.

Specified sealant: Three bond 1215 or equivalent

2. PROPELLER SHAFT

Install the propeller shaft to the companion flange, aligning with matchmark as closely as possible.

Tightening torque

50-60Nm (500-600kg·cm, 37-44lb·ft)

3. AXLE SHAFT ASSEMBLY


 Apply specified sealant to the axle housing and bearing case end faces.


Specified sealant: Three bond 1104

 Install the axle shaft assembly after installing new O-ring into the axle shaft.

COMPONENTS

EILB0330





Disassembly steps

- 1. Lock plate
- 2. Side bearing nut
- 3. Bearing cap
- 4. Differential case assembly
- 5. Side bearing inner race
- 7. Drive gear
- 8. Lock pin
- 9. Pinion shaft
- 10. Differential case assembly
- 11. Pinion gear
- 12. Pinion washer
- 13. Side gear
- 14. Side gear thrust spacer
- 15. Differential carrier case
- 16. Differential carrier
- 17. Self-locking nut
- 18. Washer

- 19. Dirve pinion assembly
- 20. Drive pinion front shim (For preload adjustment)
- 21. Drive pinion spacer
- 22. Drive pinion rear bearing inner race
- 23. Drive pinion rear shim (For drive pinion height adjustment)
- 24. Drive pinion
- 25. Companion flange
- 26. Oil seal
- 27. Drive pinion front bearing inner race
- 28. Drive pinion front bearing outer race
- 29. Drive pinion rear bearing outer race


DISASSEMBLY EIMB7300

1. SIDE BEARING NUT

Using the special tool (09521-43001), remove the side bearing nut.

NOTE

Keep the right and left side bearing nuts separate so that they are not mixed during reassembly.




AU52-25B

2. REMOVAL OF THE DIFFERENTIAL CASE ASSEMBLY

(CAUTION

- Remove the differential case assembly slowly and carefully.
- Be caurful so that the side bearing outer race is not dropped.
- Keep the right and left side bearing outer races separate so that they are not mixed during reassembly.




H7FA0740

3. REMOVAL OF THE SIDE BEARING INNER RACES Fit the put on top of the differential case, and then use

Fit the nut on top of the differential case, and then use the special tool to remove the side bearing inner race.

NOTE


Attach the prongs of the special tool(09517-43001) to the inner race of the side bearing through the notched section in the differential case.



H7FA0750

4. REMOVAL OF DRIVE GEAR

- Make the matchmarks to the differential case and the drive gear.
- b. Loosen the drive gear attaching bolts in diagonal sequence to remove the drive gear.



A7FA0760

5. REMOVAL OF LOCK PIN (FOR CONVENTIONAL DIFFERENTIAL)




H7FA0770

REMOVAL OF SELF-LOCKING NUT



H7RA1100

10. REMOVAL OF DRIVE PINION REAR BEARING **OUTER RACE**



H7FA0810

REMOVAL OF DRIVE PINION


Make the matchmarks on the drive pinion and companion flange.




CAUTION

Matchmarks should not be made on the contact surfaces of the companion flange and the propeller shaft.

b. Drive out the drive pinion together with the drive pinion spacer and drive pinion front shims.




H7FA0820



H7FA0790

REMOVAL OF DRIVE PINION REAR BEARING IN-**NER RACE**



H7RA1090

REMOVAL OF OIL SEAL / DRIVE PINION FRONT BEARING INNER RACE / DRIVE PINION FRONT **BEARING OUTER RACE**

INSPECTION

EIJB0490

- Check the companion flange for wear or damage.
- Check the bearings for wear or discoloration.
- 3. Check the gear carrier for cracks.
- Check the drive pinion and drive gear for wear or
- Check the side gears, pinion gears and pinion shaft for wear or damage.
- Check the side gear spline for wear or damage.


REASSEMBLY EIUC0810

Install the drive pinion rear bearing outer race and drive pinion front bearing outer race using the special tools (09500-11000, 09500-21000, 09532-31200B and 09532-32000).



(!) CAUTION

Be careful not to press in the outer race when it is inclined.



EIJA005C


ADJUSTMENT OF PINION HEIGHT

Adjust the drive pinion height according to the following procedures:

 Install the drive pinion inner and outer bearing races to the special tools (09500-43131, 09500-4A000) in sequence shown in the illustration.

NOTE

Apply a thin coat of the multipurpose grease on the mating face of the washer of the special tool.



EIUC081A

2. Tighten the nut of the special tool slowly until the standard value of drive pinion turning torque is obtained.



FILICOR1E


 Measure the drive pinion turning torque (without the oil seal) using the special tool (09532-11600).

STANDARD VALUE:

Bearing division	Bearing Iubrication	Rotation torque Nm (kg·cm)
New	None (with anti-rust agent)	0.6-0.9 (6-9)
New or reused	Oil application	0.4-0.9 (4-9)

NOTE

- Gradually tighten the nut of the special tool (09500-43131, 09500-4A000) while checking the drive pinion turning torque.
- Because the special tool cannot be turned one rotation, turn it several times within the range that it can be turned. After obtaining smooth bearing operation, measure the rotation torque.




EIUC081C

 Position the special tool in the side bearing seat of the gear carrier and select a drive pinion rear shim of a thickness which corresponds to the gap between the special tools.

NOTE


- Clean the side bearing seat thoroughly. When
 positioning the special tool, confirm that the
 cut-out sections of the special tools touch the
 side bearing seat very closely.
- When selecting the drive pinion rear shims, use the fewest number of shims necessary.

[NO. 6]




ESRDS53C

[NO. 7]



EIUC081D

5. Fit the selected drive pinion rear shim(s) to the drive pinion, and press-fit the drive pinion rear bearing inner race using the special tool (09535-11000).



AIJA030A

ADJUSTMENT OF DRIVE PINION PRELOAD

Adjust the drive pinion turning torque according to the following procedures:

- Fit the drive pinion front shim(s) between the drive pinion spacer and the drive pinion front bearing inner race.
- 2. Tighten the companion flange to the specified torque using the special tool (09517-21700).



Do not install the oil seal.




H7RA1100

3. Measure the drive pinion turning torque (without the oil seal) using the special tool (09532-11600).

Standard value:

0.4 - 0.5 Nm (4 - 5 kg·cm, 0.296 - 0.37 in.)



H7FA0940

 If the drive pinion turning torque is not within the range of the standard value, adjust the turning torque by replacing the drive pinion front shim(s) or the drive pinion spacer.


NOTE

When selecting the drive pinion front shim pack, use the minimum number of shims.

Remove the companion flange and drive pinion once again.


Insert the oil seal into the gear carrier front lip using the special tool (09517-21000).

Apply multipurpose grease to the oil seal lip.



H7RA1080

 Apply a thin coat of multipurpose grease to the contacting surface of the oil seal in the companion flange and contacting surface of the washer of the flange before installing the drive pinion assembly.



FIJA007B

 Install the drive pinion assembly, shim packs and companion flange with matchmarks properly aligned, and tighten the companion flange self-locking nut to the specified torque using the special tool (09517-21700).




H7RA1100

8. Measure the drive pinion turning torque (with oil seal) by using the special tool (09552-11600) to verify that the drive pinion turning torque is within the standard value.

STANDARD VALUE:

Bearing use	Bearing lubrication	Rotation torque Nm (kg·cm)
New	None (with anti-rust agent)	0.8 - 1.1 (8 - 11)
New or reused	Oil application	0.6 - 0.7 (6 - 7)

9. If it is beyond the standard value, check the torque of the companion flange self-locking nut, or the assembly condition of the oil seal.



H7FA0980


ADJUSTMENT OF DIFFERENTIAL GEAR BACKLASH

Adjust the differential gear backlash according to the following procedures:

- 1. Assemble the side gears, side gear spacers, pinion gears, and pinion washers into the differential case.
- 2. Temporarily, install the pinion shaft.



Do not install the lock pin yet.




H7FA0990

3. Insert a wedge in the side gear and measure the differential gear backlash with a dial indicator on the pinion gear.

NOTE

Measure both pinion gears separately.

Standard value: 0-0.076mm (0-0.003in.)



A7FA1000

- If the differential gear backlash exceeds the limit, adjust the backlash by installing thicker side gear thrust spacers.
- 5. Measure the differential gear backlash once again, and confirm that it is within the limit.




- After adjustment, check that the backlash is within the limit and the differential gear rotates smoothly.
- When adjustment is impossible, replace the side gear and the pinion gear as a set.
- 6. Installation of the lock pin
 - Align the pinion shaft lock pin hole with the differential case lock pin hole, and drive in the lock pin.
 - b. Fix the lock pin in place by staking two points around the lock pin hole with a punch.



H7FA1010

- 7. Installation of the drive gear
 - a. Clean the drive gear attaching bolts.
 - Remove the adhesive on the threaded holes of the drive gear with a tap (M10 x 1.25), and then clean the threaded holes with compressed air.




H7FA1020

c. Apply the specified adhesive to the threaded holes of the drive gear.


Specified adhesive: LOCKTITE #262 or equivalent

d. Install the drive gear in the differential case with the matchmarks properly aligned. Tighten the bolts to the specified torque (80-90 Nm, 800-900 kg·cm) in a diagonal sequence.




H7FA1030

8. Press-fit the side bearing inner race




A7FA1040

Align the matchmark on the gear carrier and the bearing cap, and then tighten the bearing cap.



AU52-31D

- 10. ADJUSTMENT OF FINAL DRIVE GEAR BACKLASH Adjust final drive gear backlash as follows:
 - Using the special tool(09521-43001), temporarily tighten the side bearing nut until it is in the state just before preloading of the side bearing.



AU52-25B


2) Measure the final drive gear backlash.

Standard value

No. 6: 0.11-0.16 mm (0.0043-0.0063 in.) No. 7: 0.13-0.18 mm (0.0051-0.0071 in.)

NOTE

Measure at lease 4 point on the drive gear periphery.




AU52-32A

3) Using the special tool(09521-43001), adjust the backlash to standard value by moving the side bearing nut as shown.


NOTE

First turn the side bearing nut for loosening, and then turn(by the same amount) the side bearing nut for tightening.




EIMB750D

4) Using the special tool(09521-43001) to apply the preload, turn down both right and left side bearing nut on half the distance between centers of two neighboring holes.



AU52-32C

5) Choose and install the lock plates two kinds.




AU52-32D

- 6) Check the final drive gear tooth contact. If poor contact is evident, make adjustment.
- Measure the drive gear runout.

Limit: 0.05mm (0.0020in.)

8) When drive gear runout exceeds the limit, remove the differential case and then the drive gears, moving them to different positions and reinstalling them.




AU52-32A

LIMITED SLIP DIFFERENTIAL (LSD)

LIMITED SLIP DIFFERENTIAL (NO.6) EILBO350

COMPONENTS



- 1. Differential case (LH)
- 2. Differential case (RH)
- 3. Differential shaft lock pin
- 4. Differential clutch disc guide
- 5. Differential clutch preload spring guide
- 6. Differential clutch preload spring
- 7. Differential clutch side gear
- 8. Differential clutch friction disc, eared
- 9. Differential pinion thrust washer
- 10. Differential pinion gear
- 11. Differential pinion shaft
- 12. Differential clutch friction disc, splined
- 13. Differential clutch disc shim

DISASSEMBLY EILB0360

Using a screw driver, remover the 4 screws on the flange.


NOTE

· Before removal, make matchmarks.



AlJA0301

• If the case halves are not separated, tap the heads of the screws lightly with a punch and a hammer as shown in illustration.




AIJA0302

Remove the screws, L.H. case, L.H. shim, L.H. gear sub-assembly (side gear, disc pack, and ear guides), preload plate and two preload springs from the R.H. case assembly.


NOTE

Keep these parts separate so that they can be reassembled in the same location as they were originally.



EIJA0303

3. Drive out the cross shaft lock pin using a 4 mm diameter rod and a hammer.




EIJA0304

Remove the cross shaft from the side gear.

NOTE

The cross shaft must be removed toward the side where the lock pin hole is located as shown in the illustration.




- 1. DRIVE OUT LOCK PIN
- 2. DRIVE OUT CROSS SHAFT
- 3. REMOVE REMAINING PARTS

AIJA0305

5. Follow the same procedure for the opposite side case.

NOTE

Do not mix R.H. and L.H. parts.



EIJA0306



- Check the side gears, pinions, pinion thrust washers, and cross shaft for wear or damage. If there is excessive wear, cracks, nicks, grooves or galling, replace the parts.
- Inspect the carbon surfaces. After cleaning with a solvent, the carbon surface should appear a course weave fabric with flat spots on the peaks of the weave. If the surface is smooth, either from wear or from the weave filled with debris, replace the entire disc pack.
- Measure the thickness of the carbon friction discs.
 If the measurements is below the limit value, replace the disc.


Clutch discs	Limit value
Double sided discs	 2.06 mm
Single sided disc	 1.65 mm

4. Inspect the splined friction discs. If they have grooves or are polished, replace the entire disc pack. Small scratches on them are O.K.

SHIM SELECTION FOR CLUTCH DISC

- Measurement for R.H. pocket
 Measure the R.H. pocket with the pinion shaft in stalled as shown in illustration.
- Measurement for L.H. pocket
 Measure the L.H. pocket with the pinion shaft installed
 according to the following formula as shown in illustration.


L.H. POCKET = A + B - C



Measurement for the pocket (LH/RH)

AIJA0307

3. Measurement for the side gear sub height.
As shown in illustration, install the clutch disc, side gear, preload spring and spring plate, and then adjust the clearance of the preload spring by applying the pressure at both sides till it is 32mm as shown in illustration. At this time, measure the height of side gear sub at RH, LH sides by measuring the length of "D"



AIJA0308

- 4. Seclecting shims by the side gear sub height
 - a. Used disc

Shim thickness = RH(LH) pocket - RH(LH) side gear sub height - 6.45

b. New discShim thickness = RH(LH) pocket - RH(LH) sidegear sub height - 6.20

NOTE

- · Adjust the shim thickness within 0.08mm.
- When replacing one disc, replace all of the discs.
- 5. The specifications of the clutch disc shim


Part No. (EATON NO.)	Shim thickness
EDS98754 - 10	0.010′
EDS98754 - 15	0.015′
EDS98754 - 20	0.020′
EDS98754 - 30	0.025′
EDS98754 - 35	0.030′
EDS98754 - 40	0.035′
EDS98754 - 45	0.040′

REASSEMBLY EILBO370

1. Install the clutch disc guide and clutch disc in order.




Apply grease to the clutch disc guide and clutch disc before reassembly.




EIJA0309

- 2. Install the clutch preload plate and side gear.
- 3. After assembling the pinion shaft, pinion gear and washer, fix the pinion shaft lock pin with a hammer.




EIJA0310

4. Install the preload spring and spring plate in the opposite side .



EIJA0311

5. After assembling the clutch disc and side gear in the opposite case, assemble the two cases.



EIJA0312


6. Assemble the case by tightening the torx screws driver.



ElJA0301

LIMITED SLIP DIFFERENTIAL (NO.7) EILBO380

COMPONENTS



- 1. Case
- 2. Washer-lock
- 3. Screw-lock
- 4. Guide-ear
- 5. Plate-preload
- 6. Spring-preload
- 7. Gear-side
- 8. Eared disc S/A (carbon on both sides)
- 9. Thrust washer-pinion
- 10. Pinion gear
- 11. Cross shaft-pinion
- 12. Disc-splined friction
- 13. Shim-side gear
- 14. Eared disc S/A (carbon on one side)

TORQUE: Nm (kg·cm, lb·ft)

DESCRIPTION EILBO390

This Carbon Disc Limited Slip Differential has a one piece case. Inside the case is a bevel gear set. The gear set has two side gears and two pinion gears. Each pinion gear is held in place by a spherical thrust washer and the cross shaft. The cross shaft fits into the holes in the case. The cross shaft is retained by a threaded lock pin with a lock washer. Behind each side gear is a friction disc pack. Between each disc pack and the internal pockets of the case is a shim. The thickness of these shims is selected to provide the correct backlash between the side gears and pinion gears. Between the side gears are a spring preload assembly and a thrust block. The preload plates are constructed so they straddle the cross shaft, hold the preload springs and position the thrust block.

DISASSEMBLY FILBO400


- 1. Remove the threaded lock screw and the cross shaft.
- Remove the spring preload assembly. Use a hammer and punch to drive the spring plates out from the large window.
- Without preload on the side gears, they can be turned by hand. Rotate the side gears until the pinions are in the window area. Remove the pinions and pinion thrust washers.
- 4. Remove the gear sub-assemblies (side gear, disc pack, ear guides and disc pack shims). Do not mix parts. Identify the parts so they can be reassembled to the original location.

INSPECTION EILBO410

- Check the side gears, pinions, pinion thrust washers, thrust block and cross shaft for wear or damage.
 If there is excessive wear, cracks, nicks, grooves or galling, replace the parts.
- Inspect the carbon surfaces. After cleaning with a solvent, the carbon surface should appear like a course weave fabric with flat spots on the peaks of the weave. If the surface is smooth, either from wear or from the weave filled with debris, replace the entire disc pack.
- Measure the thickness of the carbon friction discs. If any of the double sided discs are less than 2.56 mm or the single sided disc is less than 2.15 mm, replace the entire disc pack.
- 4. Inspect the splined friction discs. If they have grooves or a mirror like finish, replace the entire disc pack. Small scratches on a buff like finish is okay.


REASSEMBLY AND SHIM SELECTION EILBO420

- Apply axle lubricant to all sliding surfaces. Be especially careful to coat the mating surfaces of the friction discs.
- 2. Starting with a double sided eared disc next to the side gear, stack four eared discs and three splined discs on to the spline of the side gear. A splined disc goes in between each eared disc with the last eared disc being single sided and the carbon surface facing the side gear. Use a heavy bearing grease in the ear guides to hold them in place during assembly.




H7RA1240

- 3. Select a shim 0.76 mm (030") thick and place on the hub side of the disc pack subassembly.
- 4. Lubricate and assemble the other side gears as above.
- 5. Install the flange end side gear subassembly and shim in the flange end of the differential case.
- Position pinion gears and thrust washers on the side gears and install the cross shaft through the case and pinions.
- 7. Install a dial indicator on the case.
- 8. Compress the clutch pack with a large screw driver or pry bar as shown. Rotate the pinion gear back and forth to obtain backlash. Tooth backlash should be 0 to 0.10 mm (0 to .004"). If required, change the .76 mm shim to obtain the proper backlash.




H7RA1250

- Remove the side gear subassembly and repeat the tooth backlash procedure for the other gear pack on the opposite side of the case.
- 10. Remove the cross shaft, pinions and thrust washers and reinstall the first side gear subassembly and shim in the flange end of the case.
- 11. Install a pinion and thrust washer through each window so that the gear teeth mesh and so that the pinions are in line with each other. Rotate one side gear so the pinions and thrust washers rotate at a position where they line up with the cross shaft holes in the case.
- 12. Mount springs and load plates in a vise. With the thrust block between the spring plates, compress the assembly until the load plates touch. Install a "C" clamp on the plates and install 6 mm bolts through each front spring. Retain nuts on the screws as shown in the illustration.




H7RA1230

13. Position the spring pack between the side gears and remove the "C" clamp.



H7RA1190

- 14. Drive the spring pack into the side gears far enough to retain the springs. Then remove the 6 mm bolts and complete the pack installation by driving the spring pack in position so that the cross shaft can slide through the middle as shown. Turn the thrust block so that the hole in the middle lines up with the hole in the case.
- 15. Install the pinion shaft, lock screw and lock washer. Tighten the lock screw to 30-40 Nm (22-29 lb.ft) torque.



H7RA1170

