# Clutch System

| GENERAL         | CH -2 |
|-----------------|-------|
| OLUMNIA OVOTERA | CH -4 |
| CLUTCH SYSTEM   |       |

CLUTCH SYSTEM

## GENERAL

#### SPECIFICATIONS EOUB0010

| Clutch disc<br>Type<br>Outer Diameter | mm (in.)     | Dry, single plate<br>240 (9.48): 4D56 TCI, SIRIUS-II, T-2<br>254 (9.87): A-2.5 TCI |
|---------------------------------------|--------------|--|
| Facing material Spline                |              | Non-asbestos<br>23 teeth   |
| Clutch cover                          |              | 20 100111  |
| Type                                  |              | Diaphragm spring type  |
| Setting load                          | N (Kg, lbs.) | 4067 (415,914)   |
| Operating system                      |              | Hydraulic System   |
| Release bearing                       |              | Self-centering type  |
| Release cylinder diameter             | mm (in.)     | 19.05 (0.75)   |

#### SERVICE SPECIFICATIONS EOUB0020

| Item  | Standard          | Limit        |
|---|-------------------|--------------|
| Clutch pedal height                                 | 170.9 (6.8)       |              |
| Clutch pedal free play                              | 6-13 (0.24-0.51)  | -            |
| Distance between clutch pedal and floorboard when   | 55 (2.16) or more | ·            |
| clutch is disengaged                                |                   |              |
| Clutch pedal stroke                                 | 155 (6.2)         |              |
| Clearance between clutch master cylinder and piston |                   | 0.15 (0.006) |
| Clutch disc facing rivet sink                       |                   | 0.3 (0.012)  |

mm (in.)

## TORQUE SPECIFICATIONS EOUB0030

| Item                                  | Nm      | kg.cm     | lb.ft   |
|---------------------------------------|---------|-----------|---------|
| Clutch shaft nut                      | 19 - 28 | 190 - 280 | 14 - 21 |
| Clutch master cylinder mounting bolt  | 10 - 15 | 100 - 150 | 8 - 11  |
| Clutch tube flare nut                 | 15 - 20 | 150 - 200 | 11 - 14 |
| Clutch release cylinder mounting bolt | 30 - 42 | 300 - 420 | 22 - 30 |
| Clutch release cylinder eye bolt      | 20 - 25 | 200 - 250 | 14 - 18 |
| Clutch release cylinder bleeder screw | 7 - 9   | 70 - 90   | 5 - 7   |
| Clutch cover attaching bolt           | 15 - 22 | 150 - 220 | 11 - 16 |
| Oil chamber mounting bolt             | 8 - 12  | 80 - 120  | 6 - 9   |

# SPECIAL TOOLS EOLBOOSO


| SPECIAL TOOLS EOLBOOSO                                     |              | Use                                       |
|--|--------------|---|
| Tool (Number and name)  09411-43000 Clutch alignment arbor | Illustration | Centering the clutch disc when installing |
|  | E-           | 1143000                                   |

| ROUBL             | ESHOOTING EOLBOOGO  | Probable cause   | Remedy    |
|-------------------|---|--|-----------|
| Symptom           |   |  | Adjust    |
| Clutch slipping   |   | Insufficient pedal free play                                 | Replace   |
|                   |   | Excessive wear of clutch disc facing                         | Replace   |
|                   |   | Hardened clutch disc facing, or oil oil surface              | Replace   |
|                   |   | Damaged pressure plate or flywheel                           | Replace   |
|                   |   | Weak or broken pressure spring                               |           |
|                   |   | Excessive clutch pedal free play                             | Adjust    |
| Difficult (       | gear shifting<br>ise during shifting)                     | Bad clutch fluid, or air mixed in (hydraulic type)           | Repair    |
| (gear no          | ise during some so  | Unusual wear on corrosion of clutch disc spline              | Replace   |
|                   |   | Excessive vibration (distortion) of clutch disc              | Replace   |
|                   |   | Insufficient play of clutch pedal                            | Adjust    |
| Clutch            | When clutch is not used                                   | Excessive wear of clutch disc facing                         | Replace   |
| noisy             |   | Unusual wear and/or damage of release bearing                | Replace   |
|                   | A noise is heard after clutch                             |  | Repair    |
|                   | is disengaged  A noise is heard when clutch is disengaged | Insufficient grease on the sliding surface of bearing sleeve |           |
|                   |   |  | Repair    |
|                   |   | Improperly installed clutch assembly or release bearing      | Replace   |
|                   | A noise is heard when vehicle                             | Damaged pilot bearing  | A Company |
|                   | is suddenly rolled with clutch                            |  | Danair    |
|                   | partially engaged   | Insufficient lubrication of clutch shaft                     | Repair    |
| Hard pedal effort |   | Insufficient lubrication of clutch disc spline               | Replace   |
|                   |   | Insufficient lubrication of clutch release lever shaft       | Repair    |

# **CLUTCH SYSTEM**


# CLUTCH COVER AND DISC

COMPONENTS EOLBO280



#### REMOVAL

- Insert the Special Tool in the fly-wheel pilot bearing hole to keep disc from falling off.
- Loosen the clutch cover tightening bolt gradually in a crisscross fashion.
- Remove the clutch cover. Then pull out the Special Tool and remove the clutch disc.



#### INSPECTION

#### **CLUTCH COVER**


- Check the diaphragm spring tip for wear.
- Check strap plate rivet for looseness. 2.
- Check the pressure plate surface for damage.
- Check pivot ring for wear.


## W NOTE

To check for pivot ring wear, shake clutch cover. If noise is produced, pivot ring is worn.

#### **CLUTCH DISC**

- Check facing for loose rivets, uneven contact, deterioration due to seizure, and presence of oil or grease.
- 2. Check torsion spring and friction washer for looseness, fatigue and damage.





EOLB030A

#### CLUTCH DISC FACING WEAR MEASUREMENT


 Use caliper gauge to measure the dimension from the facing surface to the rivet head.

Limit: 0.3 mm (0.012 in.)

2. If the measured value is below the limit, replace clutch disc.

## **NOTE**

If facing is excessively worn, check flywheel and clutch cover pressure plate for wear.



EODA018A


#### INSTALLATION EOLB0310

#### **CLUTCH DISC**

1. Apply specified grease to clutch disc spline.

Specified grease: HYUNDAI Genuine Grease


- 2. Use the Special Tool to set clutch disc to flywheel.
- 3. When installing clutch disc, be sure that surface having manufacturers stamped mark (indicated by an arrow in the illustration) is on pressure place side.



EOLB031A

#### **CLUTCH COVER**


Install clutch cover with dowel pin hole in alignment with dowel pin in flywheel and tighten bolts gradually in a crisscross fashion.



EOLB031B

## **CLUTCH MASTER CYLINDER**

#### COMPONENTS EOLB0210



EOLB021A


#### DISASSEMBLY EOLB0220

- Remove the piston stopper ring.
- Remove the piston assembly.



## **CAUTION**

Do not damage the master cylinder body and piston assembly. Do not disassemble piston assembly.



EOLB022A

#### INSPECTION EOLB0230


- Check the inside cylinder body for rust or scars.
- 2. Check the piston cup for wear or deformation.
- 3. Check the piston for rust or scars.
- 4. Check the clutch tube connection part for clogging.
- Measure the master cylinder inside diameter and the piston outside diameter with a cylinder gauge and a micrometer.

Limit: 0.15 mm (0.06 in.)



#### NOTE

Measure the inside diameter of the master cylinder at three places (bottom, middle, and top) each in two perpendicular directions.




EODA014A

If master cylinder-to-piston clearance exceeds the limit, replace the master cylinder and/or piston assembly.

#### REASSEMBLY EOUB0240

Apply specified clutch fluid to the inner surface of the master cylinder body and to the entire periphery of the piston assembly.


Specified clutch fluid: Brake fluid SAE J1703 (DOT 3 or DOT 4)



EOLB024A

Apply the specified sealant to contact surface of piston and boot.

Specified sealant: Metal Rubber #20.



EOLB024B

#### **CLUTCH PEDAL**

# CLUTCH PEDAL INSPECTION AND ADJUSTMENT EOUBOO70


 Measure the clutch pedal height and the clutch pedal backlash.

#### Clutch pedal height

Standard value: 170.9 mm (6.8 in.)

#### **NOTE**


Clutch pedal height is non-adjustable. If the height is outside the standard value, check for deformed pedal bracket, etc. and replace parts as required.



Confirm that the clutch pedal free play and the clearance to the floor board when the clutch is disengaged, are within the standard values.

Clutch pedal free play (Including clevis pin play)


Standard value: 6 - 13 mm (0.24 - 0.51 in.)



Distance between the clutch pedal and the floor-board when the clutch is disengaged

Standard value: 55 mm (2.16 in.) or more

Distance between the clutch pedal and the floorboard when the clutch is disengaged



EOLB007C

If the clutch pedal play exceeds the standard value, adjust the play with the double nut on the push rod on the master cylinder side.




#### / CAUTION

Be careful not to push the push rod toward the master cylinder.



Adjustment of the clutch pedal free play must be made by using push rod double nut on master cylinder after assembling.



EOLB007D

**CLUTCH SYSTEM** CH -9

#### **BLEEDING**


Whenever the clutch tube, the clutch hose, and/or the clutch master cylinder have been removed, or if the clutch pedal is spongy, bleed the system.



## **CAUTION**

Use the specified brake fluid. Avoid using a mixture of the specification fluid and other fluid.


Specified brake fluid: Brake fluid SAE J1703 (DOT 3 or DOT 4)



EOKA004A

**CLUTCH SYSTEM** 


#### COMPONENTS EOLB0170



EOUC018A

#### REMOVAL EOUC0180

- Loosen nut on the clutch shaft before removing the split pin to reduce the turn over spring force.
- 2. Remove the split pin of the spring assist rod.



#### INSPECTION EOLB0190


- Check the pedal shaft bushing for wear.
- Check the pedal shaft for bend. 2.
- 3. Check the pedal arm for bend or torsion.
- 4. Check the clutch tube and reservoir hose for cracks or clogging.
- Check the turnover spring for deterioration. 5.
- Check the pedal pad for damage or wear.

#### INSTALLATION EOUC0200

#### MASTER CYLINDER

Apply specified grease to clevis pin and washer.

Multipurpose grease: SUN LIGHT #2 or RETINAX A.




EOLB020A

#### CLUTCH PEDAL AND CLUTCH SHAFT

Apply specified grease to all connecting and sliding parts before assembly.

Specified grease:


Chassis grease SAE J310, NLGI NO.0



EOLB020B

#### ATTACHING NUT AND SPRING ASSIST ROD

After installing the clutch shaft and the clutch pedal, install the spring and the spring assist rod.




EOUC020A

CH -12 CLUTCH SYSTEM

#### **CLUTCH RELEASE CYLINDER**

#### COMPONENTS EOLB0250



#### EOKA013A

#### DISASSEMBLY EOLB0260

1. Before removing the clutch tube, discharge the clutch fluid at the bleeder screw of the release cylinder.

#### **INSPECTION**


- 1. Check the clutch release cylinder for fluid leakage.
- 2. Check the clutch release cylinder boot for damage.

#### REASSEMBLY EOLB0270

 Apply a coating of the specified grease to the contact parts of the release fork and release cylinder push rod.

Specified grease:

Wheel bearing grease SAE J310, NLGI NO.2



EOLB027A

2. Fill reservoir tank with specified fluid after attaching clutch tube.

Specified grease:
Brake fluid SAE J1703 (DOT 3 or DOT 4)

3. Purge air and check for leaks.